


MAINTENANCE MANUAL

INSTANDHALTUNGSANLEITUNG
MANUEL D'ENTRETIEN
ISTRUZIONI PER LA MANUTENZIONE




970.381.00.0(01)







1




2




3




4




5




6




7



8




9




2


1



i




2




3


1




2



3




4




4


1




2






3



4






i





🚰/🚰



Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com

