





ENJOY WATER®

38 562





Modellnummer	X1	X2
38 541, 38 546, 38 554, 38 555, 38 557	646-1070	455-755
38 786, 38 803	795-1070	560-755
38 528, 38 531, 38 536, 38 539, 38 593, 38 624, 38 721, 38 722, 38 728, 38 750, 38 760, 38 763, 38 764, 38 772, 38 775, 38 813, 38 827	700-1070	495-755
38 525, 38 526, 38 591 38 618, 38 622, 38 761 38 767, 38773	780-1070	550-755

