



No.	Code	Name	No.	Code	Name
1	576529	CAP ASM.	48	576540	SCREW
3	574400	SCREW	49	613643	SCREW
4	576530	CAP	50	576556	MAGAZINE COVER
5	613593	SEAL	51	613653	SPRING WASHER
6	613594	SPRING	52	613604	SUPPORT PLATE
8	576531	O-RING	53	576557	SELF TAPING SCREW
9	613596	PISTON HEAD VALVE	54	613634	ROLLED PIN
10	613597	O-RING	55	576550	PUSHER ASM.
11	613598	SEAL	56	576543	ADJ. BOLT
12	576579	O-RING	57	576555	SPRING GUIDE
16	576532	DRIVER ASSEMBLY	58	576544	CONTACT ARM
17	576533	COLLAR	59	576549	SPRING
18	576534	CYLINDER	60	576548	MAGAZINE ASM.
20	576535	BUMPER	61	576559	MODEL LABEL
21	613606	SET PLATE	62	617626	ROLLED PIN
22	576536	GASKET	63	617417	ROLLED PIN
23	576537	BODY	64	617420	ADJ. WHEEL
24	613031	ROLLED PIN	65	617415	CONTACT TRIP BLOCK
26	576542	ROLLED PIN	66	617413	SET SHAFT
27	617850	SPRING	67	617602	HOOK
28	617601	C-RING	68	613053	SPRING
32	576538	RUBBER GRIP	69	576580	TRIP GUIDE
36	613644	SCREW	77	576541	STOPPER
37	613643	SCREW	80	576539	EXHAUST COVER
38	613641	NOSE COVER	82	613124	SWITCH ASM.
39	613630	SCREW	86	613123	TRIGGER ASSEMBLY
40	576581	DRIVER GUIDE PLATE	89	576547	SPRING
41	576546	NOSE	92	576582	E-RING
42	576545	SPRING	98	613642	SPACER
43	576553	CORE TRIP	99	574414	SPACER
45	613645	RUBBER PAD			
46	576552	MAGAZINE			
47	576554	NAIL LINER			